

X5 Wireless Speaker User Manual

Tips:

iPad and tablet connections, please refer to the above method of the phone connection;

- Connection for laptop: because of laptop different Bluetooth version range, if can not connect with the player in the first time, you may need to install the new version of Bluetooth driver on a laptop, referring to instruction manual of notebook computer.

play music

- Play via Bluetooth:

1. In accordance with the above method to connect the music device and speakers paired.
2. Go to the music player on the device, choose your favorite music through speaker.
3. Short press to pause the music and again to replay.
4. (Volume - / previous track, volume + / next song) button: long press to decrease the volume, short press to previous song. Long press to increase the volume, short to next song.

- Play via AUX IN function:

1. Insert the aux in to the speaker and another end to the device with bluetooth staying on.
2. Select the music to play directly on the music device.
3. Meanwhile, it will close the playing sound pressing the play/pause button, but the music continues to play on the device. In AUX IN mode, multi-function button (Volume - / previous track, volume + / next song) can not adjust the previous / next song.

- Play via TF card function:

1. Insert the TF card into the TF card slot on the side of the speaker to play music.
2. Short press to pause the music and again to replay.
3. (Volume - / previous track, volume + / next song) button: Long press to decrease the

Thank you for choosing " X5 " wireless speaker . Please read the user manual carefully for proper instruction .

Notes before use

This product is designed with full attention safety performance. To ensure safe operation, please follow the following rules:

- Place the speakers in a stable position avoid fall and cause damage or personal injury.
- Do not drop, disassemble, open, crush, bend, puncture, burn speaker.
- Do not use the speakers near water and immersed in any liquid or place any liquids dripping spilled on the speakers.
- speaker above is strictly prohibited to place any appliance filled with water, such as vases; do not place any form of open flame in the speaker, such as a lit candle.
- Do not close to any heat source (such as radiators, heating equipment, stoves, or other heat-generating equipment) where the use of speakers.
- Please send professional maintenance staff repair for any reason damage.
- Before wiping with a dry cloth to clean the speakers, set the power switch to the off position and unplug the power cord from the power outlet.
- health considerations, please adjust the sound to a suitable level.

Package includes

1. X5 wireless Speaker x 1
2. Micro USB charging cable x 1
3. 3.5mm standard audio cable x 1
4. Carabiner x 1
5. Product Manual x 1

Applicable models

volume, short press to previous song. Long press to increase the volume, short to next song.

4. Press the fuselage insert TF card, TF card will pop for easy pick.

Volume adjustment

Press the +/- keys to adjust the volume or volume on the device.

Bluetooth handsfree

1. Connect your phone via Bluetooth, the speaker will play ringtones when call coming.
2. Short press the multifunction key to answer the call on the speaker, you can talk through the microphone hole, after call ended, it will continue to play music.
3. Long press the answer button on the speaker to reject an incoming call.
4. When paired with the phone, press twice in rapid multifunction key to call back the last call by telephone.

Explanation

1. The symbol indicates: This product is only suitable for the safe non-tropical climates.
2. Note: If the battery is incorrectly replaced explosion, only the same type or equivalent type of battery to replace.
3. The lithium battery can not be placed to sunlight, such as fire or the like excessive heat.

Technical Parameters

All specifications are subject to change without notice.

- Product name: X5 wireless Speaker
- Model: X5
- power modes: 5V USB power supply
- Battery capacity: 3.7V, 800Mah

• perfect support for iPhone, iPad series, smart phones, tablet computers and other audio devices with Bluetooth connectivity.

• applies to MP3, computers, mobile phones, tablet PCs, game consoles with 3.5mm standard headphone jack of the device, through the distribution of audio cable to connect with the product.

feature of product

- X5 is a suitable for iPhone, iPad, smart phones, tablet computers and other devices connected with Bluetooth hands-free speaker.
- Stylish exterior design, easy to carry in travel or in-door entertainment, enjoy the fun of music. Both support music and wireless hands-free answering phone calls.
- AUX IN function matched MP3, mobile phones, game consoles and other devices with 3.5mm standard headphone jack also with TF card reader playback, offering a variety of entertainment options.
- Easily connect compatible Bluetooth devices in the effective distance of 8-12 meters from smartphones to the iPhone, iPod, iPad, netbooks, notebooks.
- Fashion mini shape music system design and built-in rechargeable lithium battery, supporting to be used in indoor and outdoor after charged.
- Bluetooth handsfree when playing music, short press the answer button on the speaker, then talk to each other in the front of the speaker. After call ended, the speaker phone will continue to play music. Long press the answer button on the speaker to reject the call.
- Multi-audio input can support Bluetooth wireless connected to music phones, MP3 and other portable devices via AUX IN and TF card music playback.

- Output Power: RMS 3W x 1
- Bluetooth: V4.1 + EDR
- Working distance: 8-12 meters

Cleaning and Maintenance

Following instructions to clean

- For safety sake, before you start cleaning, disconnect the power supply
- Wipe gently with a soft cloth
- Never use a volatile substance
- If product unused for long periods, disconnect the power and place into the original box with the protective packaging.
- Do not place the product in damp, high temperature or in direct sunlight

Fault and Maintenance

One problem: unsuccessful pairing connection.

solution:


- (1) Please check whether the multifunction indicator light flashes blue. If the light is off, power on your speakers, if the light still does not turn on, please charge the speaker.
- (2) Too much Bluetooth device receiving in surrounding, resulting in search difficulties, turn off the other Bluetooth device.
- (3) Power off and then on, restart speaker Bluetooth search function or restart playback devices Bluetooth search function.

Second problem: the music player appears staccato.

solution:

- (1) Check the distance between the player and the speaker has not been exceeded effective

Part names and functions



1. carabiner hole
2. The multi-function buttons: play/pause/answer call
3. +: Long press to increase the volume, short to next song
4. -: Long press to decrease the volume, short press to previous song
5. Power button: Long Press to power on, short press to transfer the playing mode
6. USB charging hole
7. AUX IN cable connection interface
8. TF card slot
9. microphone hole
10. The charge indicator
11. Bluetooth indicator

Bluetooth connection distance 8-12meters.

- (2) Check whether there is an obstacle between the playback device and speakers.
- (3) Check the playback device, or whether the speaker is in a low power state.

Power on/off

Power on: Long press to power on the speaker with sound tones, then the Bluetooth indicator light is on and you can pair with bluetooth devices.

Power off: Long press to power off with bluetooth indicator off.

Select the playback mode

Bluetooth default boot status, TF card player and AUX IN three kinds of play mode. When insert into the AUX line or TF card, it will automatically switch to the corresponding mode. When AUX IN and TF card get access to the speaker, short press the power button to switch to playback mode.

1. Bluetooth mode: via Bluetooth wireless technology to play the device music.
2. TF Card Mode: TF card music playback;
3. AUX IN mode: Play music from the AUX IN devices source.

Connect your phone and tablet via Bluetooth:

The first pair (take smart phones example)

Power on the speaker to automatically enter into the Bluetooth mode with sound tones, then the bluetooth indicator flash fast and you can pair the device now.

Bluetooth pairing

1. Open the Bluetooth search setting.
2. Search in the device list " X5 ", click the link directly, without a password to fast pair. When coming out the sound prompt and the blue indicator light slow flashes, it indicates cell phones and speaker have been successfully paired. At this point you can easily play music!



Capricorn Elements
Believing Creativities
www.capricornelements.com

Dear Customer,

This model is an upgraded model for X5. You will see 'X5A' as its Bluetooth device name on your mobile phone. This model does not support TF/MicroSD card. This model added new Twin Speaker feature. The Twin Speaker feature allows one X5 to pair with another X5 to give stereo sound stage.

To pair two X5 speakers into Twin Speaker mode:

1. Power on two X5 speakers.
2. Press and hold the PLAY/PAUSE buttons of two X5 speakers for >10sec until the connected beep tone is heard.

To temporary unpair two X5 speakers from Twin Speaker mode:

1. When in Twin Speaker mode, press and hold the PLAY/PAUSE button of the slave X5 speaker until the disconnect beep tone is heard.

Note:

When next time the two X5 speakers power on, they will automatically re-connect back to Twin Speaker mode.

To permanently unpair two X5 speaker from Twin Speaker mode:

1. When in Twin Speaker mode, press and hold the PLAY/PAUSE button of the host X5 speaker until the disconnect beep tone is heard.

Note:

When next time the two X5 speakers power on, they will not re-connect back to Twin Speaker mode.